

# Wiring Diagram

1. CG110S2-CCP, One Gang Curtain Control Switch
2. CG110S4-CCP, Two Gang Curtain Control Switch

Notes: The Neutral wire of load is closely connected to the Neutral point of CG110.

