

Wiring Diagram

- 1. CG130S2xx-CCP, One Gang Curtain Control Switch
- 2. CG130S4xx-CCP, Two Gang Curtain Control Switch

Notes: The Neutral wire of load is closely connected to the Neutral point of CG130.

