

Wiring Diagram

1. CG800S2xx-CCP, One Gang Curtain Control Switch
2. CG800S4xx-CCP, Two Gang Curtain Control Switch

Notes: The Neutral wire of load is closely connected to the Neutral point of CG800.

